







IT CHOPS FOOD GRINDS MEAT PAGE 23

IT PUREES AND RICES







IT SHARPENS KNIVES







Index to Recipes

CAKES AND COOKIES . . . . . . . . . . . PAGE

IT OPENS CANS PAGE 33

ZONE DE LA CONTRACTOR DE	
EDOCTINGS	 . PAGE 13
LKO311MG3	 · FAGE 13





MASHED POTATOES, VEGETABLES, ETC. PAGE 15

MAYONNAISE & SALAD DRESSINGS ... PAGE 16



IT SHELLS PEAS PAGE 37



PAGE 17

DESSERTS & MISCELLANEOUS . . . . . . . . .



## BANANA VANILLA WAFER PIE

2¼ c. milk ¾ c. granulated sugar ½ c. flour

1/4 tsp. salt 3/4 c. cold water 2 egg yolks 1 tsp. vanilla extract
¼ tsp. lemon extract
3 bananas
1 tbsp. lemon juice
Whipped cream
6 vanilla wafers

• Scald milk. Mix sugar, flour and salt in small bowl of Mixmaster and add cold water slowly, using No. 1 speed. Add the beaten egg yolks and beat until blended. Slowly add the hot milk. Cook in a double boiler until thick, stirring constantly. Cool and add extracts. Slice bananas into a baked pastry shell and sprinkle with lemon juice. Cover with the cream mixture. Cool and top with whipped cream. Put 6 vanilla waters through Meat Grinder and Food Chopper Attachment of Mixmaster, using No. 10 speed, and sprinkle over whipped cream as a garnish.

There's no end to the every day usefulness of this double-purpose attachment. The easiest to use of all Meat Grinders and Food Choppers. The safest.



Grind wafers, etc., for delicious pastry garnishes with Meat Grinder and Food Chopper Attachment.

## **MEAT BALLS**

Use the Meat Grinder and Food Chopper Attachment for grinding the beef and raw potatoes used in this appetizing dish.



Grind nut meats of all kinds, for icings, confections, etc., quickly, evenly.





For stuffings, bread puddings, croquettes, etc., it's a marvel. Grinds and chops evenly, quickly, safely!

## STUFFED TOMATOES

1 package macaroni
½ gal. boiling water
1 tbsp. salt

Parsley

1 c. melted butter
Fresh tomatoes
Buttered bread crumbs

• Plunge contents of 1 package of macaroni in large saucepan containing 2 quarts boiling water. Add salt. Boil until macaroni is tender; then remove and drain. Place Meat Grinder and Food Chopper Attachment on Mixmaster and run through stale dry bread for bread crumbs. Mixmacaroni with melted butter and use necessary amount to stuff tomatoes. Top with buttered bread crumbs and bake in moderate oven (350°F.) until tomatoes are tender. Caution: Do not overbake or tomatoes will not hold their shape. Place remaining buttered macaroni on hot platter and nestle stuffed tomatoes in the macaroni. Garnish platter with water cress or parsley. Serve very hot.

## eep your MIXMASTER out



Mixmaster occupies a small amount of space in your kitchen, therefore, you should keep it readily accessible. Keep it where it is convenient to use at a moment's notice at all times. In this way you will use it for every meal, every day and save yourself more time and arm-work. One of the first things you should do is select or prepare a good, permanent location for your Mixmaster, a place where it will always be plugged in ready for instant use at the turn of the switch. A double outlet for this purpose is inexpensive and convenient.

